Edge-corE

Table of Contents

1 Issue Fixed

1.1 The AP sometimes resets to default when CAPWAP is enabled if the AP is powered off.

When CAPWAP is enabled, the AP repeatedly builds the CAPWAP tunnel to write the configuration to flash. If the AP is powered off at the same time, there is a possibility that the AP will reset to default values. In this version, the issue has been resolved.

2 Compatible Version for AP Management

Compatible with EWS series v3.91.0000 and above.